

IT 设备机柜安装指南

IT Equipment Rack Mounting Guide

- 设备进风口应朝向冷通道，禁止设备装反

Equipment air intake should face to cold aisle, back-to-front installation is prohibited.

- 机柜空余 U 位应安装盲板

Please install blanking panel at empty unit.

- 设备发热量越大，应越往机柜底部装

Higher heat equipment should be racked at lower unit in cabinet.

- 托管区域禁止存放可燃物

Combustible material is prohibited in colocation space

如需帮助请联系 LOCC/For assistance please contact LOCC:

- SH2 & 3 Tel: +86-021-34057773/34057774
- SH5 Tel: +86-021-60434111/60434112
- SH6 Tel: +86-021-34057801/34057802