

## IT 设备机柜安装指南

### IT Equipment Rack Mounting Guide

- 设备进风口应朝向冷通道，禁止设备装反  
Equipment air intake should face to cold aisle · back-to-front installation is prohibited.
- 机柜空余 U 位应安装盲板  
Please install blanking panel at empty unit.
- 设备发热量越大，应越往机柜底部装  
Higher heat equipment should be racked at lower unit in cabinet.
- 托管区域禁止存放可燃物  
Combustible material is prohibited in colocation space

如需帮助请联系 LOCC/For assistance please contact LOCC:

- SH2 & 3 Tel: +86-021-60369700/60369701
- SH5 Tel: +86-021-51567211/51567212
- SH6 Tel: +86-021-38139665/38139666